



The drawings below show the recess dimensions for typical Vario 200 series cooktop combinations. The installer can find out the suitable cut-out dimensions for the combinations most frequently used by referring to the previous pages and the sketches below and on the next page.

Installation dimensions for the Vario 200 series.


$11 \frac{5}{16}''$ (288)	Appliance
$-\frac{6}{8}''$ (-20)	Overhang
$10 \frac{9}{16}''$ (268)	Cutout




$11 \frac{5}{16}''$ (288)	Appliance
$\frac{3}{16}''$ (5)	VV 200
$11 \frac{5}{16}''$ (288)	Appliance
$22 \frac{7}{8}''$ (581)	
$-\frac{6}{8}''$ (-20)	Overhang
$22 \frac{1}{16}''$ (561)	Cutout




$11 \frac{5}{16}''$ (288)	Appliance
$\frac{3}{16}''$ (5)	VV 200
$11 \frac{5}{16}''$ (288)	Appliance
$\frac{3}{16}''$ (5)	VV 200
$11 \frac{5}{16}''$ (288)	Appliance
$34 \frac{7}{16}''$ (874)	
$-\frac{6}{8}''$ (-20)	Overhang
$33 \frac{3}{8}''$ (854)	Cutout



$11 \frac{5}{16}''$ (288)	Appliance
$\frac{3}{16}''$ (5)	VV 200
$11 \frac{5}{16}''$ (288)	Appliance
$\frac{3}{16}''$ (5)	VV 200
$11 \frac{5}{16}''$ (288)	Appliance
$\frac{3}{16}''$ (5)	VV 200
$11 \frac{5}{16}''$ (288)	Appliance
$45 \frac{15}{16}''$ (1167)	
$-\frac{6}{8}''$ (-20)	Overhang
$45 \frac{3}{16}''$ (1147)	Cutout



$11 \frac{5}{16}''$ (288)	Appliance
$\frac{3}{16}''$ (5)	VV 200
$22 \frac{13}{16}''$ (580*)	Appliance
$27 \frac{9}{16}''$ (700**)	Appliance
$34 \frac{3}{8}''$ (873*)	
$39 \frac{1}{8}''$ (993**)	
$-\frac{6}{8}''$ (-20)	Overhang
$33 \frac{9}{16}''$ (853*)	Cutout
$38 \frac{3}{16}''$ (973**)	




* VE, VG26


** VE

Installation dimensions for the Vario 200 series with VL downdraft.


$11 \frac{5}{16}''$ (288)	VE, VF...
$\frac{3}{16}''$ (5)	VV 200
$3 \frac{3}{8}''$ (85)	VL 041
$14 \frac{7}{8}''$ (378)	
$-\frac{9}{16}''$ (-13.5)	Overhang
$14 \frac{3}{8}''$ (364.5)	Cutout




$11 \frac{5}{16}''$ (288)	VE, VF...
$\frac{3}{16}''$ (5)	VV 200
$3 \frac{3}{8}''$ (85)	VL 041
$\frac{3}{16}''$ (5)	VV 200
$11 \frac{5}{16}''$ (288)	VE, VF...
$26 \frac{7}{16}''$ (671)	
$-\frac{6}{8}''$ (-20)	Overhang
$25 \frac{5}{8}''$ (651)	Cutout
	(=approx.650)



$3 \frac{3}{8}''$ (85)	VL 041
$\frac{3}{16}''$ (5)	VV 200
$22 \frac{13}{16}''$ (580)	VE, VG26...
$\frac{3}{16}''$ (5)	VV 200
$3 \frac{3}{8}''$ (85)	VL 040
$29 \frac{15}{16}''$ (760)	
$-\frac{1}{4}''$ (-7)	Overhang
$\frac{1}{8}'' + \frac{1}{8}''$	
$(3.5 + 3.5)$	
$29 \frac{9}{16}''$ (753)	Cutout



$11 \frac{5}{16}''$ (288)	VE, VF...
$\frac{3}{16}''$ (5)	VV 200
$3 \frac{3}{8}''$ (85)	VL 041
$\frac{3}{16}''$ (5)	VV 200
$22 \frac{13}{16}''$ (580)	VE, VF...
$37 \frac{15}{16}''$ (963)	
$-\frac{6}{8}''$ (-20)	Overhang
$(10+10)$	
$37 \frac{1}{8}''$ (943)	Cutout



How to calculate? General Rules.

First calculate the overall dimension of the cooktop set up. Do this by adding each unit's overall width and add $\frac{3}{16}''$ for each connecting strip used. Once you have the final figure for the overall dimension, deduct the overlap of the cooktop set up at each end (starting and ending unit).

Cut-out dimension = Overall dimension. The overlap at each end (total overlap).

Between each unit (cooktops and ventilators) a connecting strip should be placed and added to the overall dimension of the cooktop set up.

The Vario 200 series does not have finishing strips.

When installing only one unit, the cut-out dimension is $10 \frac{9}{16}''$ for the 12" units, $22 \frac{1}{16}''$ for the VE 260 614 and VG 264 214 CA.

Numbers indicated
inside parenthesis () = mm